

## **SWAGELOK - screw connection**

**H745.1**

**Assembly instructions for SWAGELOK-screw connection  
(Fine regulation-, and stop-valve for high-pressure autoclaves)**



1. Insert the tube section (6 mm) of the thread adapter completely into the SWAGELOK screwed pipe fitting.
2. Tighten the screw fitting hand-tight.
3. Final positioning is obtained by turning the screw nut  $1\frac{1}{4}$  times clockwise.



**Technical** **INFO**